



Installation Instructions for PP145 Snow Guard

- A. Determine snow guard placement on roof. The first row is typically installed above the exterior load bearing wall.
- B. This bracket must be fully supported to achieve proper seal with roof.
- C. Consult with an engineer, snow guard manufacturer or fastener company to determine the fastener required for attaching the base to the substructure. A minimum of 4 fasteners are required for each bracket.
- D. Insert the included black EPDM cone shaped bushings into the countersinks on the bottom of the bracket.
- E. Place bracket on the roof in selected location.
- F. Fasten the bracket using selected fasteners.
- G. Caulk the perimeter of the bracket and fastener heads.
- H. Install pipes, couplings, end caps, and end collars. (NOTE: You will have to stagger the collars from outside to inside on 3 pipe styles.)

Snow guard layout for pipe style brackets

- Contact the manufacturer for detailed layout.
- Do not install runs of snow retention bar more than 100 feet long without a break to allow for thermal expansion.
- First row of snow guards are installed above outer most wall or support of the building.

Document version 04.24.2015

